


COMPLI 500

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части -




43137-04


①	Steuerung	Control unit
	510/4, 515/4	
	525/2, 525/4	
	535/2	
②	DN150 / DN100	DN 150 / DN100
③		
④		
⑤		
⑥		
⑦		
	510/4, 515/4	
	525/2, 525/4	
	535/2	
⑧		
⑨		
⑩		
⑪		
	510/4	
	515/4	
	525/4	
	525/2	
	535/2	
⑫		
⑬		
⑭		
⑮		
⑯		



①	Steuerung	Control unit
	1010/4 BWE	
	1010/4, 1015/4	
	1025/4, 1025/2	
	1035/2	
②	DN 150 / DN 100	DN150 / DN 100
③		
④		
⑤		
⑥		
⑦		
⑧	4 m Leitung	
	15 m Leitung	
⑨		
⑩		
⑪	1010/4 BWE, 4 m	
	1010/4 BWE, 15 m	
	1010/4	
	1015/4	
	1025/4	
	1025/2	
	1035/2	
⑫		
⑬		



①	Leitung	Cable	
	10/4, 15/4, 25/4		JP43717
	1010/4 BWE, 4 m		JP43721
	1010/4 BWE, 15 m		JP48685
②	Stator + Gehäuse	Stator + Housing	
	10/4, 15/4, 25/4		JP47042
	1010/4 BWE		JP43722
③	Rotorwelle	Rotor shaft	
	10/4, 15/4, 25/4		JP45791
	1010/4 BWE		JP46801
④	Motorabdichtung	Motor seals	JP46806
⑤	Lauf radbefestigung	Impeller fixation	
	10/4, 15/4, 25/4		JP46802
	1010/4 BWE		JP46803
⑥	Lagersatz	Bearing set	JP46724
⑦	Lagerschild	Bearing housing	JP43720
⑧	Dichtungssatz	Seal set	JP46807
⑨	Lauf rad	Impeller	
	1010/4 BWE		JP47290
	10/4		JP45793
	15/4		JP45794
	25/4		JP45795
⑩	Schraubensatz	Screw set	JP47291

[illegible]